# GOODWE

# GW3500-9100K-MVS Smart Transformer Station User Manual



# Content

1. About This Document5
1.1. Intended Audience5
1.2. Manual Description 5
1.3. Safety Precautions8
1.3.1. General Safety Rules8
1.3.2. Electrical Safety10
1.3.3. Mechanical Safety12
1.3.4. Environment Requirement13
1.3.5. Transportation Requirement15
1.3.6. Storage Requirement15
2. Product Introduction17
2.1. Product Overview17
2.1.1. Function17
2.1.2. Appearance19
2.1.3. Dimensions
2.1.4. Nameplate24
2.2. Components Introduction25
2.2.1. LV Room25
2.2.2. Transformer Room
2.2.3. MV Room30
2.2.4. Power distribution room37

3. Installation 39
1. Hot and Cold Commissioning39
4.1. Introduction39
4.1.1.Introduction to main equipment for cold commissioning .39
4.1.2. MVS Interlocking and Key Diagram40
4.1.3. Interlocking Type between MVSs42
4.2. Cold Commissioning54
4.2.1. Overall Inspection before Cold Commissioning54
4.2.2. Insulation Test73
4.2.3. Device testing inside the MVS7
4.2.4. Hot Commission Readiness Setting83
4.3. Hot Commissioning85
4.3.1. Pre-hot Commissioning Inspection Program8
4.3.2. UPS Circuit Power-On92
4.3.3. RMU Power-On93
4.3.4. Power On the Transformer98
4.3.5. Power on the Auxiliary Circuit99
4.3.6. Power on the LV Circuit99
4.3.7. Running without Load10
4.3.8. Running with Load102
5. Routine maintenance105
5.1. Precautions105

5.2. Power off and Shut down fo	or Maintenance107
5.2.1. Transformer	107
5.2.2. Ring Main Unit	111
5.2.3. Cables between Ring Main	Units112
5.3. Routine maintenance	118
5.4. Common parts replacemen	t123
5.4.1. Replacement of Arrester	123
5.4.2. Replacement of Air Circuit	Breakers 125
5.4.3. Replacement of Molded Ca	se Circuit Breakers127
5.4.4. Oil surface temperature ga	auge replacement 129
5.4.5. Replacement of Micro Circ	uit Breakers133
5.4.6. Replacement of lighting la	mps135
5.4.7. Replacement of smoke ser	nsor135
5.4.8. Replacement of heater	137
5.4.9. Replacement of Measuring	and controlling Device138
5.4.10. UPS replacement	140
5.4.11. Replacement of the Heat	Exchanger Rain Shield 142
5.4.12. Replacement of the air co	nditioner144
5.4.13. Replacement of the Moist	ture Absorber146
5.5. Paint repairing	147
6. Technical Parameters	155
7. Appendix	158

#### 1. About This Document

#### 1.1. Intended Audience

This manual is intended for maintenance personnel. It's applicable to personnel who transport, install and operate this product. They should at least meet the following requirements:

- Have certain expertise in electronics, electrical wiring and machinery,
   be familiar with electrical and mechanical schematics diagrams.
- Be familiar with the composition and working principle of PV power generation system.
- Be familiar with the composition and working principle of MVS and it's front and rear level equipment.
- Have received professional training related to the installation and commissioning of electrical equipment.
- Have the emergency response capability to the danger or emergency in the process of installation or commissioning.
- Be familiar with the relevant standards and specifications of the country/region where the project is located, and must obtain the operation certificate of the relevant standards and specifications of the country/region where the project is located.
- Be familiar with what is described in this manual.

# 1.2. Manual Description

Please read this manual carefully before transporting and installing this

product. You can start operation only after you understand the contents of the manual. Please keep this manual and other document of parts of the product together to ensure that relevant personnel can access them at any time.

The symbols that may be found in this manual are defined as follows:

#### **ADANGER**

Indicates a high-level hazard that, if not avoided, will result in death or serious injury.

#### **AWARNING**

Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.

#### **A**CAUTION

Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.

#### NOTICE

Indicates a potential hazard that, if not avoided, could result in equipment malfunction or property damage.

Please always pay attention to the danger warning signs on the housing of the MVS, including:

### Label Explanation



This label indicates that there is a high voltage inside and touching it may cause an electric shock.

This label indicates that this is the protecting earthing (PE)



terminal, which needs to be firmly grounded to ensure operator safety.

### 1.3. Safety Precautions

The safety instructions in this manual must be strictly followed at all times. In order to avoid possible casualties and property losses during installation or operation, and to extend the service life of the MVS, please be sure to read all safety instructions.

## 1.3.1. General Safety Rules

#### **▲**DANGER

There is a danger of electric shock if you touch the power grid or the contacts, terminals, etc. inside the equipment that connected to the grid!

- Do not touch terminals or conductors connected to the power grid circuit.
- Pay attention to all instructions or safety instructions regarding connection to the power grid.
- Lethally high voltage exists inside the product.
- Heed and follow warning signs on the product.
- Observe the safety precautions listed in this manual and other documentation related to this equipment.
- Damaged equipment or system failure can cause electric shock or fire!
- Preliminary visual inspection of equipment for damage or other hazards before operation.
- Check whether other external equipment or circuit connections are

safe.

• Be sure the equipment is in a safe state before operation.

#### **AWARNING**

- The installation and operation of the MVS must comply with the relevant standards and regulations of the country where the project is located.
- Make sure that the installation environment (such as voltage, temperature, humidity, altitude, pollution level, water proof and dust proof level) is within the allowable range.
- Before operation, the locking device on the pressure relief valve must be removed.
- Mechanical installation, electrical connection, commissioning, maintenance and troubleshooting must be performed by professional technicians in accordance with local regulations. Before operation, the operator should read this manual in full and understand the safety precaution related to the operation.

#### NOTICE

- Place eye-catching warning signs at the front and rear of the MVS and at the switch to avoid accidents caused by wrong closing.
- Set up warning signs or safety tapes near the field operation area.
- The warning signs on the MVS and the electrical equipment inside contain important information for safe operation of the MVS and the internal equipment. It is strictly forbidden to tear or damage them manually.
- Ensure that the warning signs on the body are always clear and readable.
- If the warning signs on the body are damaged or blurred, they must be replaced immediately.

### 1.3.2. Electrical Safety

#### **DANGER**

- Before electrical connections, make sure that the MVS and its internal electrical equipment are in good condition. All electrical connections must comply with local country/ regional electrical standards.
- When a grounding fault occurs in a PV system, fatal high voltage may exist on the originally uncharged parts which is very dangerous if touched accidentally! Before operation, please ensure that there is no grounding fault in the system. At the same time, relevant protective measures should also be taken.
- Only when it is ensured through a display or other way that the MVS,

especially the housing of the MVS, is completely neutral, all operations can be performed on it.

- Ensure that the escape route is unobstructed during the entire operation.
- Ensure that the power-off equipment will not be accidentally re-powered. After the MVS is completely out of operation, be sure to wait at least 10 minutes before operating the MVS to ensure the complete neutrality of the MVS.
- Use a multimeter and electrical testing equipment to ensure that the complete neutrality inside the equipment.
- Necessary grounding and short-circuit connections can be done only after confirming the neutrality.
- Use insulating cloth to insulate and cover the operating parts near potentially live parts.
- There are high voltages in the equipment inside the MVS, accidental touch may cause a fatal electric shock hazard, so during live measurement, you should take precautions (such as wearing insulating gloves, etc.) and there must be accompanying personnel to ensure personal safety.

### **AWARNING**

•When conducting electrical connections, trial runs, and other operations on MVS, it is necessary to use relevant electrical

measurement equipment to ensure that all electrical parameters meet the requirements.

- The measuring range and usable conditions of the tool must meet the requirements of the site.
- Ensure that the connection and use of the measuring tool are correct and standard to avoid dangers such as arcing.

#### **⚠CAUTION**

- Touching or improperly handling printed circuit boards or other electrostatically sensitive components can damage the device. Please discharge static electricity before operation.
- Avoid unnecessary contact with circuit boards.
- Comply with electrostatic protection regulations, such as wearing an anti-static wrist strap, etc.

#### NOTICE

During daily operation, it is necessary to ensure that the doors of the MVS and the internal equipment are closed and locked, and the keys have been pulled out and handed over to a dedicated person for safekeeping in order to avoid unauthorized people entering or exposure to rain, animals, etc. of the internal equipment. At the same time, the MVS and internal equipment should be regularly inspected and maintained to ensure long-term reliable operation.

# 1.3.3. Mechanical Safety

- Please repair the paint scratches of the equipment in time. It is strictly
  forbidden to expose the scratched parts to the air for a long time
  which is easy to cause rusting.
- If you want to perform arc welding, cutting and other operations on the equipment, or install other equipment on the top of the equipment, please contact GoodWe first.
- Prohibit the use of tools with scars, expiration dates, and inspection failures, and ensure that the tools are not overloaded.
- For high-altitude operations, please refer to and comply with the relevant high-altitude operation safety codes.
- For the use of ladders, please refer to and comply with the local relevant ladder use safety codes.
- When it comes to hoisting, please refer to and comply with local safety regulations.
- It is strictly prohibited to drill holes on the equipment. Drilling holes
   can damage the leakproofness, electromagnetic shielding
   performance, internal components and cables of the equipment, and
   the generated metal chips entering the equipment can cause circuit
   board short circuits.
- For handling heavy objects, please comply with relevant safety regulations and work safely after training.

### 1.3.4. Environment Requirement

- Site selection should comply with local laws, regulations, and relevant standards.
- Do not expose the equipment to flammable or explosive gas or smoke.
   Do not perform any operation on the equipment in such environments.
   Do not store any flammable or explosive materials in the equipment area. Do not place the equipment near heat sources or fire sources.
- Ensure that the equipment is stored in a clean, dry, and well-ventilated area with proper temperature and humidity and is protected from dust and condensation.
- It is strictly prohibited to install and operate the equipment in an environment that exceeds the scope of technical specifications or is harmful to the container. Otherwise, the performance and safety of the equipment will be affected.
- Do not install, use, or operate outdoor equipment and cables in harsh weather conditions.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water accumulation, and the horizontal level of the site must be above the highest water level of that area in history. Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in

addition to routine weeding, harden the ground underneath the equipment using cement or gravel

- Before installation, operation, and maintenance of the equipment,
   clean up any water, ice, snow, or other foreign objects on the top of the
   equipment to prevent foreign objects from falling into the equipment.
- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment. After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

### 1.3.5. Transportation Requirement

- Choose appropriate means of transportation based on the dimensions and weight of the equipment. The equipment should be placed horizontally during transportation to prevent being deformed or scratched by collision.
- Stacking layer should not exceed the allowable maximum layers, the equipment should be placed neatly, and the tilt angle should not exceed 15° during transportation.
- For road transport, a road survey must be conducted in advance to identify obstacles on the route to ensure that vehicles can pass through the route; for water transport, it is necessary to ensure that the route meet the full load navigation of the ships.

### 1.3.6. Storage Requirement

- The equipment is placed horizontally during storage and the container doors are closed tightly. Store the equipment in a clean and dry place, and prevent the erosion of dust and water vapor.
- The temperature and humidity of the storage environment are proper (-35°C~70°C, and 5%~95%RH). Otherwise, the equipment may be damaged.
- For extended periods of storage, place silica gel moisture absorbent packs in the MVS based on the site environment, and check and replace the silica gel moisture absorbent packs on a regular basis. After extended periods of storage, test the equipment in accordance with local laws and regulations and applicable standards before use.

### 2. Product Introduction

#### **NOTICE**

The nominal capacity of this product is 9100kVA, and in practice it can cover the scenarios used where the capacity is smaller than the nominal parameter.

#### 2.1. Product Overview

#### **2.1.1. Function**

A Medium Voltage Substation (MVS) converts low-voltage (LV) AC power generated by solar inverters into medium-voltage (MV) AC power and feeds it into a power grid.

It is a steel-structure container that includes devices include the LV cabinet,

MVS transformer, ring main unit, measuring and controlling device, and auxiliary transformer to provide a highly integrated power transformation and distribution solution for utility-scale PV plants in MV grid-connection scenarios.

Each MVS is connected upstream to the equipment on the substation side through a ring main unit, and downstream to the equipment on the inverter side through a LV cabinet.

The typical application diagram is as follows:




Figure 2-1 MVS Typical Application Diagram

# 2.1.2. Appearance

### SF6 MVS Smart Transformer Station




Figure 2-2 Appearance





Figure 2-3 Component

1 LV(Low voltage) room	1.1 LV Cabinet
2 Transformer room	2.1 Transformer

3	MV(Medium m	voltage)	3.1 Ring main unit (RMU)
4 Power distribution room		n room	4.1 Auxiliary transformer
		11100111	4.2 UPS


### SF6 Free MVS Smart Transformer Station




2 Transformer room	2.1Transformer	
3 MV(Medium voltage)	3.1 Ring main unit (RMU)	
4 Power distribution room	4.1 Auxiliary transformer	
4 Fower distribution foom	4.2 UPS	

# 2.1.3. Dimensions

#### SF6 MVS Smart Transformer Station





SF6 Free MVS Smart Transformer Station




Figure 2-4 Container dimensions

# 2.1.4. Nameplate





Figure 2-5 Nameplate

Label	Label Name	Explanation	
		The equipment operates at high	
		voltage. Only qualified and	
	Electric shock	trained electrical technicians are	
<u></u>	warning	allowed to install and operate the	
		equipment.	
		Indicates the position for	
	Cuavadina	connecting the protecting	
	Grounding	earthing (PE) cable.	



# 2.2. Components Introduction

### 2.2.1. LV Room

The low-voltage room mainly includes secondary equipment. The main components are as follows:




Figure 2-6 LV Room Structure

1. LV Cabinet	2. Heat exchangers

### LV Cabinet Interior:





Figure 2-7 LV Room Structure

1. Air circuit breaker	2. Molded	case	circuit	3. Wiring area
	breaker			

# 2.2.2. Transformer Room

#### SF6 MVS Smart Transformer Station



#### SF6 Free MVS Smart Transformer Station




Figure 2-8 Structural layout of transformer room

When a fault occurs inside the transformer, a significant amount of gas will be produced, causing the sharp pressure increase inside the transformer. When the gas content is low, the transformer alarms. When the gas content reaches the activation pressure, the oil will be discharged, rapidly reducing the internal pressure of the transformer to the normal level. At the same time, a trip signal is sent out to trip the circuit breaker of the ring main unit.

# 2.2.3. MV Room




Figure 2-9 MV Room Layout

# 2.2.3.1. DAQO 24, 40.5kV Ring Main Unit




Figure 2-10 Ring main unit DQS-40.5 CVC appearance

1 Earthing switch	2 Load switch	3 Three position
operating hole	operating hole	disconnector
4 Circuit breaker	E donaimates	China diamban
operation buttom	5 densimeter	6 Live display




Figure 2-11 Ring main unit DQS-24 DVC appearance

1 Earthing switch	2 Load switch	3 Three position
operating hole	operating hole	disconnector
4 Circuit breaker	5 Operation	C Fauth hav
operation buttom	handle	6 Earth bar




Figure 2-12 Ring main unit DQS-40.5 DVC appearance

1 Earthing switch	2 Load switch	3 Three position
operating hole	operating hole	disconnector
4 Circuit breaker	5 Operation	6 Earth bar
operation buttom	handle	o carui bar

# 2.2.3.2. ABB 24, 40.5kV Ring Main Unit





Figure 2-13 Ring main unit SAFE 12/24 CCV appearance






Figure 2-14 Ring main unit SAFE 40.5 CCV appearance

1 Load break	2 Earthing switch	3 Three position
switch	2 Earthing Switch	disconnector
4 Push bottons	5 Push bottons	6 densimeter
close	open	o densimeter

# 2.2.3.4. Siemens 24, 36kV Ring main unit




Figure 2-15 Ring main unit 24kV RRL appearance

1 Load break	2 Earthing switch	3 Three position
switch		disconnector
4 Push bottons	5 Push bottons	
close	open	





Figure 2-16 Ring main unit 36kV RRL appearance

1 Load break	2 Earthing switch	3 Three position
switch	2 Earthing Switch	disconnector
4 Push bottons	5 Push bottons	
close	open	

Index: See the RMU user manual for details.

### 2.2.3.5. Schneider RMU



### 2.2.4. Power distribution room




Figure 2-17 Power distribution cabinet front view layout Figure




Figure 2-18 Smart Communication Unit appearance

Index: See the Smart Communication Unit (SCU3000A) user manual for details.



Figure 2-19 QR code for SCU3000A User Manual

### 3. Installation

Please check the Installation Manual and strictly follow the steps in the manual for installation. <u>GW3500-9100K-MVS Smart Transformer</u>

Station Installation Guide

## 4. Hot and Cold Commissioning

#### 4.1. Introduction

# 4.1.1.Introduction to main equipment for cold commissioning





Figure 4-1 Cabinets

Name	Туре	Location	Function
G1	Switchgear	Inside the	Incoming cable cabinet
G2	Switchgear	Inside the	Vacuum circuit breaker cabinet
G3	Switchgear	Inside the	Outlet cable cabinet
D1	Switchgear	LV Room	Connecting to inverters
D2	Switchgear	LV Room	Connecting to inverters
P cabinet	Power distributio n cabinet	Near the ring main unit	Power distribution device installation

Refer to the project electrical label on the device for the specific functions.


## 4.1.2. MVS Interlocking and Key Diagram



Note: \*:K9 and K11 are optional and please adhere to the products delivered.

Figure 4-2 Interlocking Diagram

The key locations of different types of RMU (ring main unit) are shown in the following figure:



### 4.1.3. Interlocking Type between MVSs

#### NOTICE

- The G1 cabinet of each MVS points to the grid side. The G1 and G3 cabinets is not allowed to be swapped, otherwise it will cause interlocking disorder between MVSs.
- Each MVS and each switch will has a unique number. The number of the corresponding MVS and the specific switch number will be marked on the key plate.

### 4.1.3.1. Normal Interlocking

(1) The introduction to the normal key interlocking device of G1 cabinet with load switches in CCV/CVC type cabinet is as follows:

The purpose of normal interlocking is to prevent the downstream earthing switch from closing misoperation. As shown in figure, one of the interlocking devices is installed near the operating shaft of the earthing switch in the upstream G3, and the other interlocking device is installed near the operating shaft of the earthing switch in the downstream G1.




Figure 4-3 The normal interlocking of G1 cabinet with load switch

If the earthing switch in upstream G3 is in the open position, the key cannot be pulled out from the key interlocking device. The G1 earthing switch on the downstream side can be closed only when the earthing

switch on the upstream G3 cabinet is closed.

#### **Procedure**

- **Step 1:** Place the load switch which is in the upstream G3 in an open position.
- **Step 2:** Place the earthing switch in an closed position.
- **Step 3:** After step 1 and 2, then the key interlocking device can be operated.
- **Step 4:** Take out the key and insert it into the key interlocking device on the earthing switch of downstream G1. After unlocking the earthing switch, the downstream earthing switch can be closed.




Figure 4-4 CCV type ring main unit normal interlocking




Figure 4-5 CVC type ring main unit normal interlocking

(2) The introduction to the normal key interlocking device for G1 cabinet without load switch in DCV/DVC type cabinet is as follows:

As shown in Figure, one of the interlocking devices is installed near the operating shaft of the earthing switch in the upstream G3, and the other key is on the cable room door in the downstream G1.




Figure 4-6 The normal interlocking of the G1 cabinet without load switch

If the earthing switch in upstream G3 is on an open position, the key cannot be pulled out from the key interlock. The downstream G1 cable room door can be opened only when the earthing switch on the upstream G3 cabinet is closed.

First, the load switch in the upstream G3 must be placed in an open

position and the earthing switch must be placed in the open position. Only then can the key interlocking device be operated, that is locking the upstream earthing switch in the closed position. Then you can take out the key and insert it into the cable room of downstream G1. After unlocking, the cable room can be opened.




Figure 4-7 The normal interlocking of the DVC ring main unit




Figure 4-8 The normal interlocking of the DCV ring main unit

# 4.1.3.2. (Optional requirement: G1 cabinet with load switch) A3 Interlocking

The purpose of the A3 key interlocking device is described in the following example:

As shown in the figure, one of the interlocking devices is installed near the operating shaft of the load switch in the upstream G3, and the other interlocking device is installed near the operating shaft of the earthing switch in the downstream G1.




Figure 4-9 A3 Interlocking

If the load switch in upstream G3 is in a closed position, the key cannot be pulled out from the key interlock. The downstream G1 earthing switch can be closed only when the load switch on the upstream G3 cabinet is open.

First, the load switch must be placed in an open position. Only then can the key interlocking device be operated and can the key be turned, that is locking the load switch in the open position. Then after you take out the key and insert it into the interlocking device of the earthing switch of downstream G1, the earthing switch can be opened.




Figure 4-10 The A3 interlocking of the CCV ring main unit




Figure 4-11 The A3 interlocking of the CVC ring main unit

# 4.1.3.3. (Optional requirements: G1 cabinet with load switch) P1 Interlocking

The purpose of the P1 key interlocking device is described in the following example:

The purpose of P1 interlocking is to ensure absolutely safe operation of the upstream G3 and downstream G1 by avoiding the closing of the upstream or downstream earthing switch since there is power supply both upstream and downstream to.

As shown in the figure, one of the interlocking devices is installed near the operating shaft of the earthing switch in the upstream G3, and the other interlocking device is located near the load switch; the same interlocking device is installed near the operating shaft of the earthing switch in the downstream G1, and another interlocking device is located near the load switch.




Figure 4-12 P1 Interlocking

If the load switch in the upstream G3 is in a closed position, the key cannot be pulled out or rotated in the key interlock device. The downstream earthing switch can be closed only when the load switch in the upstream G3 is opened. If the load switch in the downstream G1 is in a closed position, the key cannot be pulled out or turned in the key interlock device. The upstream earthing switch can be closed only when the downstream G1 load switch is opened.

From upstream to downstream, the load switch must first be opened in the upstream G3, and then the key interlocking device can be operated to lock the load switch in the open position. Then you can pull out the key and insert it into the key interlocking device on the earthing switch of downstream G1, and the earthing switch can be closed.

From downstream to upstream, the load switch must first be placed in an open position in downstream G1 before the key interlocking device can be operated and interlocking the load switch in the open position.

Then you can pull out the key and insert it into the key interlocking device on the upstream G3 earthing switch to unlock it, and then close

the earthing switch.




Figure 4-13 The P1 interlocking of the CCV ring main unit




Figure 4-14 The P1 interlocking of the CVC ring main unit

### 4.2. Cold Commissioning

The specific steps for cold commissioning after the completion of installation are as following:

- 1) Overall inspection;
- 2) Insulation test;
- 3) Testing of components inside the MVS;
- 4) Hot commissioning preparation status setting.

### 4.2.1. Overall Inspection before Cold Commissioning

### 4.2.1.1. Overall Appearance Inspection of Container

Steps	Operation	Yes/No	Note
	The appearance of the container should be		
	intact and free of rust or paint damage. If		
1	there are abnormalities, rust removal and		
	touch-up work will be required. Please refer to		
	the "Troubleshooting Manual" for details.		
	The labels and nameplates of the equipment		
_	must not be damaged or lost, and the writing		
2	should be clear and legible. If not, the label		
	and nameplate should be replaced.		

# 4.2.1.2. Check the Interlocking function

Intro	oduction	to the Key Statı	us inside the M\	/S	
Interlocking device	Key name	Switch status	Key status	Yes/No	Note
G1: Earthing switch	K1	Opened	can be pulled out after unlocked		N.A.
		Closed	can not be		N.A.
G1: Load switch	K2	Opened	can be pulled out after unlocked		N.A.
		Closed	can not be pulled out		N.A.
	K3	Opened	can not be		
G2: Earthing switch		Closed	can be pulled out after unlocked		

			can not be	
G0 TI		Opened	pulled out	
G2: Three			can be	
position	K4		pulled out	
disconnector		Closed	after	
			unlocked	
		_	can not be	
G3: Earthing		Opened	pulled out	
switch			can be	
(normal	K5		pulled out	
interlocking)		Closed	after	
			unlocked	
			can be	
G3: Earthing		0	pulled out	
switch	175	Opened	after	
(A3,P1	K5		unlocked	
interlocking)		Classil	can not be	
		Closed	pulled out	
			can be	
C2. Land with	1//	0.5.5.5.5	pulled out	
G3: Load switch	K6	Opened	after	
			unlocked	

	T			
		Closed	can not be	
		Closed	pulled out	
			can be	
		K8,K9*,K10,K	pulled out	
		11* inserted	after	
MV key container	K7		unlocked	
		K8,K9*,K10,K		
		11* not	can not be	
		inserted	pulled out	
			can be	
	K8	Door closed	pulled out	
Transformer door			after	
K8			unlocked	
		Door opened	can not be	
			pulled out	
			can be	
		Dagustass	pulled out	
Transformer door	146.	Door closed	after	
K9*	K9*		unlocked	
			can not be	
		Door opened	pulled out	
L	l	l .		

Transformer door K10	K10	Door closed	can be pulled out after unlocked can not be	
		Door opened	pulled out	
			can be	
		Door closed	pulled out	
Transformer door	K11*	Door closed	after	
K11*			unlocked	
		Door opened	can not be	
			pulled out	
		Closed	can not be	
			pulled out	
Air circuit breaker	K12		can be	
1QF in D1		Opened	pulled out	
			after	
			unlocked	
Air circuit breaker	K13	Closed	can not be	
2QF in D2			pulled out	

			can be	
		Opened	pulled out	
		Opened	after	
			unlocked	
			can be	
		K12,K13	pulled out	
MV key container	K14	inserted	after	
master control	K14		unlocked	
		K12,K13 not	can not be	
		inserted	pulled out	

Note: \*:K9 and K11 are optional and please adhere to the products delivered.

Steps	Interlocking between 1QF & 2QF and G2 three position disconnector	Yes/No	Note
1	There is a key chain K14&K4 between the G2 three position disconnector key K4 and the LV key		
	container key K14.  When the MVS leaving the factory, K4 (key chain) is		
2	inserted next to the G2 three position disconnector. At this time, K12 and K13 cannot be pulled out.		
3	After you close the G2 three position disconnector, K4 can be pulled out. (When the G2 three position disconnector is opened, K4 cannot be pulled out).		
4	After you insert K14 into the LV key container, K12 and K13 be pulled out. After you insert it into the key holes of 1QF and 2QF, K14 cannot be pulled out.		
5	Insert K12 and K13 into the air circuit breaker and turn off the air circuit breaker. K12 and K13 cannot be pulled out.		
6	Open the operating air circuit breaker, pull out K12 and K13, insert them back into the LV key container, pull out K14 and insert K4 of the key		

chain back into G2.

Steps	Interlocking between transformer door and G2 earthing switch	Yes/No	Note
	After manufacture, there are keys K8, K9		
	, K10, K11 for the four doors of the transformer in		
1	the MV key container.		
1	There is a key chain K3&K7 for the key K7 of the		
	MV room key container and the G2 earthing switch		
	key K3.		
2	When the G2 earthing switch is opened, K3 cannot		
	be pulled out.		
	After manufacture, G2 earthing switch is closed,		
3	pull out K3 and insert K7 into the MV key container		
	to unlock K8, K9, K10, K11.		
	Pull out the key from the key container, unlock the		
4	transformer door, and confirm that the key cannot		
	be removed after opening the transformer door.		
5	At this time, the MV key container K7 cannot be		
	pulled out.		
6	Close the transformer room door and pull out the		
	key, insert it back into the MV key container.		

Note: \*:K9 and K11 are optional and please adhere to the products delivered.

Steps	Normal interlocking between the MVS 1 and MVS 2 (CCV/CVC/RRL)	Yes/No	Note
1	MVS 1 is the upstream, and MVS 2 is the downstream.		
	Open the G3 load switch of MVS1, close the G3		
2	earthing switch of MVS 1, and take out the key K5 of		
	the earthing switch of MVS 1.		
	Open the G1 load switch of MVS 2, close the G1		
3	earthing switch of MVS 2, and take out the key K1 of		
	the earthing switch of MVS 2		
4	String K5 of MVS 1 and K1 of MVS 2 in key chains		
4	K5&K1.		
5	Insert the key chain to G3 of MVS 1.		

Steps	Normal interlocking between the MVS 1 and MVS 2 (DCV/DVC/RRL)	Yes/No	Note
1	MVS 1 is the upstream, and MVS 2 is the downstream.		
	Open the G3 load switch of MVS 1, close the G3		
2	earthing switch of MVS 1, and take out the key K5 of		
	the earthing switch of MVS 1.		
3	Take out the incoming cabinet door key K1 of MVS 2.		
4	String K5 of MVS 1 and K1 of MVS 2 to the key chains		
4	K5&K1.		

5 Insert the key chain into G3 of MVS 1.

Note:

1. To remove keys K8 to K11\*, key K7 must be inserted into the key container and in locked status. Keys K8, K9\*, K10, and K11\* must be unlocked in sequence from top to bottom to successfully remove them.

2. To lock keys K11\*, K10, K9\*, and K8 for K7 key removal, strictly rotate the K8~11 keys clockwise in the sequence of K11\*, K10, K9\*, and K8 from bottom to top to the locked position. At this point, these keys cannot be removed.

Note: \*:K9 and K11 are optional and please adhere to the products delivered.

# 4.2.1.3. The Inspection of LV Cabinet

Step	Project	Status Confirmed	Yes/No	Note
1	LV cabinet	The equipment is in good condition, with no rust or paint peeling. (If any paint peeled, repaint it).  Labels on the device are clearly visible. Damaged labels must be replaced prompt.  There is no damage to the appearance of micro-breakers, fuses, switching power supplies and other devices.  The wiring is neat, the connections are tight, and the wire markings are clear.  All MCCBs perform 5 closing and 5 opening operation cycle.		
2	Measuring and controlling device	The appearance is not damaged and the labels on the buttons are clearly visible.  The terminals on the back of the measuring and controlling device		

		are firmly connected, without damage, and the line markings are clear.	
3	Temperatu re and humidity controller	The appearance is not damaged, and the labels on the buttons are clearly visible.	
4	Inspection of the heat exchanger	The appearance of the heat exchanger is intact, without any damage, and is well fixed. The wires are well secured and the labels are clearly visible.  Take out the heat exchanger rain shield and screws, and install the	
		rain shield to the heat exchanger.	
5	Foreign object inspection	There is no foreign object in the low-voltage room. If there is any foreign object, please clean it.	

# 4.2.1.4. The Inspection of the Transformer

Step	Project	Status Confirmed	Yes/No	Note
		There are no cracks, scratches or		
		dents on the appearance of the		
		transformer.		
		The connection cover between the		
1	Appearance	transformer and the LV room is free		
1	inspection	of damage, rust, or paint peeling,		
		and is well sealed.		
		The external cables of the		
		transformer room are neat and free		
		of damage and burrs.		
2	Oil leakage	There is no oil leakage in the		
2	inspection	transformer.		
		The indicator is not damaged and		
3	Inspection	the cover is firmly installed.		
	of the oil	The oil temperature displayed by		
	temperatur	the white pointer of the transformer		
	e gauge	oil temperature gauge is close to		
		the nearby ambient temperature.		

		There is no damage to the	
4	Inspection of the oil level gauge	appearance of the oil level gauge, and the cover is firmly installed.	
		The indication of the transformer oil level gauge is consistent with the oil temperature-oil level curve.	
	Inspection of the moisture absorber	If the hygroscopic silica gel is dry, the color should be blue.	
5		If the color of more than half of the silica gel changed, the moisture absorber should be replaced.	
	Inspection	The appearance of the off-load tap changer is intact and without damage.	
6	of the off-load tap changer	The off-load tap changer should be set according to user requirements.  If there are no special requirements, it should be set to the rated level (level 3).	

	Inspection	There is no damage, dents or	
	of the	peeling paint on the appearance of	
	transformer	the container, and no fallen hole	
7	secondary	plugs.	
	wire	The wiring inside the container is	
	transfer	tight and not damaged, and the	
	container	wire markings are clear.	
	Inspection	The transformer oil drain hole is not	
8	of the oil	blocked.	
	drain hole	biocked.	
	The	There is no appearance damage.	
9	pressure	Remove the pressure relief valve	
	relief valve	cover and check that it has not	
		popped up.	
		There is no appearance damage	
	Gas relay inspection	or no gas inside the gas relay. If	
10		there is a small amount of gas,	
		the air can be exhausted	
		through the exhaust plug.	
		The butterfly valve is open.	

	Foreign	There is no foreign object in the	
11	object	transformer room. If so, it needs to	
	inspection	be cleaned.	

# 4.2.1.5. The Inspection of the Ring Main Unit

Step	Project	Status Confirmed	Yes/No	Note
1	Appearan ce inspection	No cracks, dents or scratches on the exterior.  The appearance of all components on the panel is intact, with no missing buttons, knobs, etc. The cable room door is closed.		
2	SF6 or SF6-Free densimete	The SF6 densimeter pointer is in the green area and is a certain distance from the yellow or red area.		
3	Vacuum circuit breaker inspection	Operate the charge lever of the vacuum circuit breaker to set the circuit breaker in the energy storage state. Open and close the circuit breaker 5 times.		

4	Inspection of the relay protection device	The appearance of each component is normal, the wiring is tight, and the writing on the wiring label is clear.	
	room		
5	G2 cable room inspection	The appearance of the arrester is normal and there is no damage. It is securely installed.  Check for foreign objects. If there is, it needs to be cleared.  After checking, close the cable room door.	
6	Short-circ uiting metallic bar inspection	Open the control compartment of RMU and check the short-circuiting metallic bar has been removed.	

## 4.2.1.6. The Inspection of the Power Distribution Room

Step	Project	Status Confirmed	Yes/No	Note
1	Overall inspectio n	All components in the power distribution room are intact, buttons and keys are clearly written, and there are no loose installations.  All wiring is tight and undamaged.  No foreign objects. If there is, it needs		
2	Inspectio n of the internal of the distributi on containe r in the distributi	to be cleared.  All components should be in good condition.  The secondary wiring is tight, undamaged, and the wiring labels are clear.  No foreign objects. If there is, it needs to be cleared.		

### 4.2.2. Insulation Test

#### **NOTICE**

- Before installing and sealing the outgoing cable, insulation test should be conducted on the LV side. If the cable wiring is completed, all MCCBs connected to the inverters need to be turned off.
- Insulation testing is mainly for the LV side.
- The LV side insulation test requires opening the PLC switch inside SCU3000A.
- Before the test, the fuse should be disconnected, and after the test,
   the fuse should be closed.
- The operation method for conducting this insulation test on CVC/CCV/DVC/DCV ring main unit cabinets is consistent.
- This manual takes CCV type ring main unit as an example, and other types please refer to this test method.

The testing schematic is shown below:




Figure 4-15 Test diagram of low-voltage cabinet D1

Steps	Insulation test for LV cabinet D1	Yes/No	Note
1	Adjust the switch according to the test diagram		
'	of LV cabinet D1.		
	Open the load switch of G1 and G3 cabinets,		
2	close the earthing switch, open the circuit		
2	breaker of G2 cabinet, open the three position		
	disconnector and close the earthing switch.		
3	Use temporary cables to ground the		
J	three-phase of D2.		
	Short circuit the three-phase busbar of D1 (as		
4	shown in the above figure), connect the positive		
	pole of the insulation tester to one of the		
	phases, and ground the negative pole.		
	Test voltage is 1000V, test duration is 1 minute,		
5	record the resistance value at 10 seconds		
	(should be greater than 10M $\Omega$ )		
6	Record the resistance value at 30s (should be		
6	greater than 10M $\Omega$ )		
	Record the resistance value at 60 seconds, then		
7	stop the test and turn off the tester (it should be		
	greater than 10M $\Omega$ )		

Use a grounding cable to discharge the test
8 circuit and remove all test cable.




Figure 4-16 Test diagram of low-voltage cabinet D2

Steps	Insulation test for LV cabinet D2	Yes/No	Note
1	Adjust the switch according to the test diagram of LV		
'	cabinet D2.		
	Open the load switch of G1 and G3 cabinets, close		
2	the earthing switch, open the circuit breaker of G2		
	cabinet, open the three position disconnector and		
	close the earthing switch.		
3	Use temporary cables to ground the three-phase of		
	D1.		
4	Short circuit the three-phase busbar of D2 (as shown		
	in the above figure), connect the positive pole of the		
	insulation tester to one of the phases, and ground		

	the negative pole.	
	Test voltage is 1000V, test duration is 1 minute,	
5	record the resistance value at 10 seconds (should be	
	greater than 10M Ω)	
6	Record the resistance value at 30s (should be	
	greater than 10M Ω)	
	Record the resistance value at 60 seconds, then stop	
7	the test and turn off the tester (it should be greater	
	than 10MΩ)	
8	Use a grounding cable to discharge the test circuit	
	and remove all test cable.	

## 4.2.3. Device testing inside the MVS

The test of the components inside the MVS needs to be powered by an external power supply. There are two types of external power supply:

- Three-phase generator (three-phase four-wire) with an output voltage of 380V.
- A single-phase generator with an output voltage of 220V (the single-phase generator charges the UPS, and the UPS supplies power to the components. The battery power may not be able to support the entire commissioning).

#### Illustration:

- Prioritizing 380V generators as all loads can be tested using 380V generators. If 220V is used, the following equipment cannot be tested: heat exchanger, air conditioners, and temperature and humidity controllers.
- The test procedures vary for different power supplies.
- Make sure all switches are open before testing.
- The switch is based on the primary and secondary electrical figures of the actual project.

## 4.2.3.1. AC 380V Generator Power Supply

Step	Operation	Yes/No	Note
4	Connect the generator power cable		
'	(three-phase four wire) to the MVS		

2	Close the relevant MCB of the UPS
3	Close the relevant MCB of ACB controller 1
4	Close the relevant MCB of ACB controller 2
5	Closed RMU related MCB
6	Closed MVS measurement and control MCB
7	Closed the meter MCB
8	Closed lighting MCB
9	Close the MCB of SCU3000A
10	Closed heat exchanger MCB
11	Closed temperature and humidity controller
11	MCB
12	Closed air conditioning MCB
13	Close the MCB of P1 socket
14	Close the MCB of P2 socket

	Power on the SCU3000A and connect it to the	
	computer, establishing communication between	
	compacer, establishing communication between	
	the inverter and the MVS. Open the website to	
	display the commissioning interface and check	
	that all signals are normal; If it is abnormal,	
15	please record the phenomenon and contact	
15	relevant personnel.	
	Please note that the door of the distribution	
	room should be open now, so a "door open"	
	warning should appear. Operate the travel	
	switch of the distribution room door and check	
	if the interface alarm disappears.	
16	Remote control operation G2 vacuum circuit	
10	breaker to open and close 5 times each.	
17	Remote control operation 1QF (ACB-1) opening	
17	and closing 5 times each.	
4.0	Remote control operation 2QF (ACB-2) opening	
18	and closing 5 times each.	
	Disconnect all MCBs of the devices in sequence,	
19	turn off UPS, disconnect all test cables, and	
	remove all external power sources.	
20	Test completed	

## 4.2.3.2. AC 220V Generator Power Supply (UPS)

### NOTICE

- The specific steps for commissioning the smart communication unit refer to its user manual.
- The specific steps for commissioning the inverter refer to the inverter user manual.

Test conditions: There is a single-phase generator on site as the external power supply.

Step	Operation	Yes/No	Note
1	Connect the generator to the MVS		
2	Close the relevant MCB of the UPS		
3	Close the relevant MCB of ACB		
3	controller 1		
4	Close the relevant MCB of ACB		
4	controller 2		
5	Closed RMU related MCB		
6	Closed MVS measurement and		
6	control MCB		
7	Closed the meter MCB		
8	Closed lighting MCB		
9	Close the MCB of SCU3000A		

	Power on the SCU3000A and connect	
	it to the computer. Open the website	
	to display the commissioning	
	interface and check that all signals	
	are normal; If it is abnormal, please	
	record the phenomenon and contact	
10	relevant personnel.	
	Please note that the door of the	
	distribution room should be open, so	
	a "door open" warning should	
	appear. Operate the travel switch of	
	the distribution room door and check	
	if the interface alarm disappears.	
11	Remote control operation G2 breaker	
11	to open and close 5 times each	
12	Remote control operation 1QF	
12	opening and closing 5 times each	
13	Remote control operation 2QF	
	(ACB-2) opening and closing 5 times	
	each	

14	Disconnect all MCBs of the devices in	
	sequence, turn off UPS, disconnect all	
	test cables, and remove all external	
	power sources.	
15	Test completed	

## 4.2.4. Hot Commission Readiness Setting

### **NOTICE**

It is recommended that cold and hot commission should be performed within a one month interval, and follow the steps below for the commissioning; Otherwise, all MCCBs, MCBs, FUSEs in the LV cabinet and P room will be disconnected.

Step	Operation	Yes/No	Note	Step
		Disconnect all MCCBs and ACBs		
1	LV cabinet	Switch the ACB  "Remote/Local" switch to		
		"Local"  Close FUSE and open all MCBs		
	Internal	Close all FUSE		
2	operation of P room distribution container	Open all other MCBs		
4	RMU	Close the G1 incoming cabinet door		
		Close the G1 earthing switch		

		(if G1: C)	
		Disconnect the G2 vacuum	
		circuit breaker	
		Disconnect the G2 three	
		position disconnector	
		Close the G2 earthing switch	
		Close G3 earthing switch	
		(If RMU: CV/DV, without G3)	
		Disconnect G3 load switch	
		(If RMU: CV/DV, without G3)	
5	RMU Remote/Local switch	Switch "Remote/Local" switch to "Local"	
6	(Measuremen t and Control Device	Check that there is no fault record in the measurement and control device inside the low-voltage cabinet.	
7	Relay Protection	Check that there is no fault record in the relay protection on the RMU of the MV room.	

## 4.3. Hot Commissioning


#### **NOTICE**

- Special protective equipment must be used during the operation, such as wearing protective clothing, insulated boots, wearing face protection helmets, insulated gloves, etc.
- It is necessary to set up the parameters correctly by professional personnel for the first running of the equipment. Incorrect settings may cause the non-compliance of the grid connection requirements of the country/region, affecting the normal operation of the device.
- The operation inside the MVS must be carried out by professional operation and maintenance personnel. Non-professional operation and maintenance personnel are prohibited from operating to avoid personal injury caused by improper operation.
- Before powering on, please ensure that the MVS is securely installed, all internal components have been installed, and all inspections before powering on have been completed.
- If any abnormalities is found during the operation, please stop any operation immediately and continue the operation only after the abnormalities are resolved.
- Before powering on, insulation pads should be laid under the feet of the work area.
- The document takes the connection of three MVSs as an example to

introduce the power-on operation.

# 4.3.1. Pre-hot Commissioning Inspection Program

The steps for hot commissioning are as shown in the Figure table.



Steps	Item		Note
		0	
1	4.3.1 Pre-hot commissioning inspection-check the		
	ring main unit, transformer, and boosting station		
2	4.3.2 UPS circuit power-on—power on the		
	protection equipment of the MVS		
3	4.3.3 RMU power-on——Ring main unit		
4	4.3.4 Transformer power-on——Impulse once		
5	4.3.5 Auxiliary circuit power-on——Power on the		
	internal equipment of the MVS		
6	4.3.6 LV circuit power-on——Power on the air		
	circuit breaker.		
7	4.3.7 No-load operation——24 hours.		
8	4.3.8 Operation with load——the inverter		
	connected to the MVS.		

## 4.3.1.1. Inspection of the Ring Main Unit (DVC/DCV/DV)


Steps	Operation	Yes/No	Note
	Check that both transformer doors		
Transformer	are closed and the door keys are		
Transformer	placed in the key container in the MV		
	room.		
	Check that the G2 earthing switch is		
	closed, the three position		
MVS 3 (DV)	disconnector is open, and the		
	vacuum circuit breaker is open. The		
	live display is off.		
	Check that the G3 earthing switch is		
	closed and the load switch is open.		
	Check that the G2 earthing switch is		
MVS 2	closed, the three position		
	disconnector is open, and the		
	vacuum circuit breaker is open. The		
	live display is off.		
	Check that the G3 earthing switch is		
	closed and the load switch is open.		
	Check that the G2 earthing switch is		
MVS 1	closed, the three position		
	disconnector is open, and the		
	vacuum circuit breaker is open. The		
	live display is off.		
	Check that the earthing switch is		
Step-up	closed, the three position		
substation	disconnector is open, and the		
	vacuum circuit breaker is open.		

Check that the switch status of the RMU matches the status in the figure

#### below:

### NOTICE


The the DAQO ring main unit (RMU) is used as an example. For RMUs from other manufacturers, please refer to the DAQO RMU.



# 4.3.1.2. Inspection of the Ring Main Unit (CCV/CVC/CV)

Steps	Operation	Yes/No	Note
Transform er	Check that both transformer doors are closed and the door keys are placed in the key container of the MV room.		
MVS 3 (CV)	Check that the G2 earthing switch is closed, the three position disconnector is open, and the vacuum circuit breaker is open. The live display is off.  Check that the G1 load switch is open and the		
	earthing switch is closed.  Check that the G3 earthing switch is closed and		
MVS 2	the load switch is open.  Check that the G2 earthing switch is closed, the three position disconnector is open, and the vacuum circuit breaker is open. The live display		
	is off. Check that the G1 load switch is open and the earthing switch is closed.		
	Check that the G3 earthing switch is closed and the load switch is open.		
MVS 1	Check that the G2 earthing switch is closed, the three position disconnector is open, and the vacuum circuit breaker is open. The live display is off.		
	Check that the G1 load switch is open and the earthing switch is closed.		
Step-up substatio n	Check that the earthing switch is closed, the three position disconnector is open, and the vacuum circuit breaker is open.		

Check that the switch status of the RMU matches the status in the figure below:



## 4.3.2. UPS Circuit Power-On

Turn on the UPS, close all switches downstream of the UPS, and ensure that the following devices are operating normally.

### **AWARNING**

Please clear alarm signal of UPS before powering up the UPS

Steps	Operation	Phenomenon	Yes/N	Note
эсерэ	operación .		0	11010
1	Close the relevant MCB of	The device display shows		
'	ACB controller 1	values		
2	Close the relevant MCB of	The device display shows		
	ACB controller 2	values		
3	Closed RMU related MCB	Relay protection enabled		
4	Closed MVS measurement	Device turned on		
4	and control MCB			
5	Closed meter MCB	Device turned on		
6	Closed lighting MCB	The light is always on		
7	Close the MCB of SCU3000A	nothing		

### 4.3.3. RMU Power-On


## 4.3.3.1. Power On the Ring Main Unit (CCV/CVC/CV)

Steps	Operation	Yes/N o	Note
MVS 3(CV)	For G2, close the three position disconnector after inserting the key and unlocking it.		
WW3 3(CV)	For G1, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
	For G3, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
MVS 2 (CCV/CVC)	For G2, open the earthing switch after inserting the key and unlocking it, and close the three position disconnector.		
	For G1, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
	For G3, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
MVS 1 (CCV/CVC)	For G2, open the earthing switch after inserting the key and unlocking it, and close the three position disconnector.		
	For G1, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
Step-up substation	Open the earthing switch after inserting the key and unlocking it, and close the three position disconnector.		
	Close the breaker		

### NOTICE

- For all MVS, waiting next to the RMU for 5min after powering on and check if the sound is normal.
- If cable bolts are not tightened or cable terminal installation is abnormal. It may produce an arc, and will produce ZiZi arc sound.

Check that the switch status of RMU matches the status shown in figure below:



## 4.3.3.2. Power On the Ring Main Unit (DVC/DCV/DV)

For G2, close the three position disconnector after inserting the key and unlocking it.

Steps	Operation	Yes/N o	Note
MVS 3(DV)	For G2, close the three position disconnector after inserting the key and unlocking it.		
MAVC 2	For G3, open the earthing switch after inserting the key and unlocking it, and close the load switch.		
MVS 2 (CCV/CVC)	For G2, open the earthing switch after inserting the key and unlocking it, and close the three position disconnector.		


	For G3, open the earthing switch after inserting the	
MVS 1	key and unlocking it, and close the load switch.	
(CCV/CVC)	For G2, open the earthing switch after inserting the	
(CCV/CVC)	key and unlocking it, and close the three position	
	disconnector.	
Step-up substation	Open the earthing switch after inserting the key and	
	unlocking it, and close the three position	
	disconnector.	
	Close the breaker	

### **NOTICE**


- For all MVS, waiting next to the RMU for 5min after powering on and check if the sound is normal.
- If cable bolts are not tightened or cable terminal installation is abnormal. It may produce an arc, and will produce ZiZi arc sound.

The status of RMU after power on is shown as below:

### DVC+DV



DCV+DV



After the RMU is powered on, check the following items:

Steps	Operation	Yes/N o	Note
	The display of G1 cabinet flash.		
MVS 1	The display of G2 cabinet is powered off.		
	The display of G3 cabinet flash.		
	The display of G1 cabinet flash.		
MVS 2	The display of G2 cabinet is powered off.		
	The display of G3 cabinet flash		
	The display of G1 cabinet flash.		
	The display of G2 cabinet is powered off.		
MVS 3 (CV or DV)	Check for any abnormal noise after the		
	RMU is powered on.		


### 4.3.4. Power On the Transformer

Steps	Operation	Yes/N o	Note
	Store energy to the vacuum circuit breaker in		
	G2 manually or electrically.		
MVS 1	Close the vacuum circuit breaker in G2		
	Check if RMU is running		
	Check if the transformer is running		
	Store energy to the vacuum circuit breaker in		
	G2 manually or electrically.		
MVS 2	Close the vacuum circuit breaker in G2		
	Check if RMU is running		
	Check if the transformer is running		
	Store energy to the vacuum circuit breaker in		
MVS 3	G2 manually or electrically.		
	Close the vacuum circuit breaker in G2		
	Check if RMU is running		
	Check if the transformer is running		

### **AWARNING**

- Check that the live display in cabinet G2 has been illuminated.
- Check if the sound of RMU is normal.
- Check if the sound of Transformer is normal
- If cable bolts are not tightened or cable terminal installation is abnormal.It may produce an arc, and will produce ZiZi arc sound.
- When transformer charged, it will produce a large buzzing sound instantly. And buzzing sound will reduce quickly about 5s later.

The status of transformer after power on is shown as below:



## 4.3.5. Power on the Auxiliary Circuit

Close all micro breaker in the P cabinet to ensure that the following equipment is operating properly.

Steps	Operation	Yes/No	Note
1	Heat exchanger		
2	Temperature and humidity controller		
3	Air-conditioning		
4	P1 socket		
5	P2 socket		
6	Insulation Monitor Device (IMD) (optional)		

### Description:

The IMD automatically performs a self-test every four hours after power-up. It is also possible to manually press the "test" button on the panel at any time.

The steps is as follows:

- 1. Connect to the negative measurement cycle for 4 seconds. The "HM" LED will then flash briefly while the LEDs on the strip light up in sequence and the internal circuit is tested.
- 2. Subsequently, connect to the positive measurement cycle for 4 seconds and the "HM" LED will now blink for a longer period of time. Similarly, the lights on the LED strip will also light up in sequence and the internal circuit will be detected.
- 3. If there are no faults the insulation test usually starts after 2 seconds.

### 4.3.6. Power on the LV Circuit

Steps	Operation	Yes/No	Note
	Take out the low-voltage room key		
	chains K4&K14 from the G2 cabinet		
ACB	of the RMU after closing the three		
unlocking	position disconnector of the ring		
	main unit, place the key K14 in the		
	low-voltage room key container, and		

	turn the key to unlock it.	
	Take out the 1QF key K12 from the	
	LV room key container, insert the	
	key into the 1QF (ACB-1) hole, and	
	rotate to unlock it.	
	Take out the key K13 of 2QF from	
	the key container in the LV room,	
	insert the key into the hole of 2QF	
	(ACB-2), and rotate it to unlock.	
	Set "Remote/Local" of ACB to	
	"Local".	
LV cabinet	Press the "ON" button and the	
LV Cabinet	circuit breaker closed.	
	Set "Remote/Local" of ACB to	
	"Remote".	

# 4.3.7. Running without Load

Steps	Operation	Yes/No	Note
1	When the above steps are completed, close		
1	all doors		
2	Keep the MVS running without load for 24		

	hours (recommended 24 hours, the specific	
	time is subject to the project)	
	After no-load running without abnormality	
3	or failure, open the container door and	
	proceed to the next step.	

# 4.3.8. Running with Load

Steps	Operation	Yes/No	Note
Power	Close all MCCBs in the low voltage		
on the	cabinet.		
inverter	Start the inverter to output current		
inverter	without alarm.		
	Check the current value and ACB		
	current value of the multi-function		
Check	meter of the LV cabinet.		
the	Check the current value displayed in		
operatin	the "Relay Protection" of the ring main		
g status	unit.		
of the	Check the current, voltage, active		
MVS	power and reactive power of the		
	measuring and controlling device.		
	Check if there is an alert.		

	Access the SCU3000 web interface and
	enter the page shown in the following
	image.
	Set the access status of IMD device in
	PID as "off", and observe the 'HM' LED
Power	of IMD in D1 of low-voltage cabinet go
ON	out after PID operation.
the PID	Set the access status of IMD device in
the PID	PID to "open", and set the switching
	cycle of IMD and PID. (IMD cycle
	running time can be set to 60min, PID
	cycle running time to 60min.), set the
	protection time of IMD and PID
	switching (can be set to 5min).

## NOTICE

Please set the relevant parameters in the following SCU3000 web site.

Datalogger Inverter	MV Station					
Operating Log Setting				IMD Status		
Array Capacity				* Access Port	Select	×
Prototype Setting			* PID8	kIMD Switch Cycle	[60,1440]	min
PID-IMD Setting			• PID&IMD Swite	ch Protection Time	[5,60]	5
Subqueue offset value					Setting	

## Description:

IMD normal operation status indication is:Green LED "WR" light is always on. Yellow LED strip:8 LEDs show the current actual insulation resistance ( $10k\omega\sim2M\Omega$ )." HM" LED light flashes long time or short time.

### 5. Routine maintenance

The components inside the MVS may age and wear out due to the influence of ambient temperature, humidity, dust, vibration, etc., leading to potential failures. Therefore, it is necessary to perform daily and regular maintenance to ensure normal operation and to extend service life. All measures and methods that help keep the MVS in good working condition belong to the scope of maintenance.

### 5.1. Precautions

### **⚠** DANGER

- Please wear insulating gloves and use insulating tools to avoid electric shock or short circuit failure.
- Do not use a wet rag to clean exposed copper bars or other potentially conductive parts.

#### **A**WARNING

- There is fatal high voltage in the equipment which may cause fatal electric shock if touched accidentally. After the equipment has been shutdown, please wait at least 10 minutes before opening doors.Before maintaining, make sure that the equipment is completely neutral.
- Only qualified and authorized personnel can perform maintenance and other operations on the MVS.
- When maintaining work, do not leave screws, washers and other

metal parts in the MVS, otherwise the equipment may be damaged.

- The entry of sand and moisture may damage the electrical equipment in the MVS or affect the performance of the equipment.
- Do not open the cabinet doors in the MVS during sandstorm season or when the relative humidity is greater than 95%.
- Maintenance work only be done when there is no wind and sand and the weather is clear and dry.
- If only turn off switches of the AC side, LV side and high-voltage side, terminals inside the MVS are still live! To avoid the risk of electric shock, before maintenance, inspection and other operations, please:
  - 1) turn off all internal switches.
  - 2) turn off all the switches of the front and rear level equipment of the MVS.
  - 3) if there are live objects nearby, please use insulating boards or tapes to shield or wrap them.
- Use a grounding cable to connect the circuit to be inspected and the main grounding circuit before performing operation and maintenance.

#### NOTICE

- Please maintain the equipment only when you are familiar with the contents of this manual and have appropriate tools and testing devices.
- During the maintenance process, please try to prevent irrelevant personnel from entering, and temporary warning signs or fences must be erected for isolation.
- If the equipment fails, please contact your dealer.
- The equipment can only be powered on again after the fault has been resolved, otherwise the fault may expand and damage the equipment.
- After the maintenance is completed, remove the ground cable between the maintained circuit and the main ground circuit.

### 5.2. Power off and Shut down for Maintenance

#### 5.2.1. Transformer

This section takes the ring main unit DVC as an example (the model of the ring main unit does not affect the power-off steps of the transformer) to introduce the power-off steps for transformer maintenance. The switch status before maintenance:




Figure 5-1 The switch status before maintenance

Steps	Operation	Yes/No	Note
1	Remote control opening LV cabinet 1QF air		
1	circuit breaker		
2	Remote control opening LV cabinet 2QF air		
2	circuit breaker		
3	Remote control opening ring main unit G2		
3	cabinet vacuum circuit breaker.		
	Manually open the three position disconnector		
4	of the ring main unit G2 on site and confirm		
	that the live display is off.		
	Manually close the grounding knife of the G2		
5	cabinet, padlock the grounding knife operating		
	hole, and install a prohibited operation sign.		
	Manually open all incoming MCCBs and use		
6	grounding cable to discharge the low-voltage		
	cabinet busbars.		




Figure 5-2 The switch status after maintenance

# 5.2.2. Ring Main Unit

This section takes the second MVS (MVS 2) as an example to introduce the power off and maintenance procedures of the ring main unit. The operation steps of DCV and CVC are the same.

The switch status before maintenance:




Figure 5-3 The switch status before maintenance:

Steps	Operation	Yes/No	Note
1	Remote control the opening of this level LV		
'	cabinet 1QF air circuit breaker.		
2	Remote control the opening of this level LV		
2	cabinet 2QF air circuit breaker.		
	G2 cabinet of this level: opening vacuum		
3	circuit breaker, opening three position		
	disconnector, closing earthing switch.		
4	Remote control the opening of the next		
	level LV cabinet 1QF air circuit breaker.		
5	Remote control the opening of the next		

	level LV cabinet 22QF air circuit breaker.	
	All G2 cabinet of the next level: opening	
	vacuum circuit breaker, opening three	
6	position disconnector, closing earthing	
	switch, and confirm that the live display is	
	off.	
	The upper lever G3 cabinet: open the load	
7	switch, observe that the live display of G3	
7	cabinet is off, and close the earthing switch.	
	Install prohibited operation signs.	
	The main circuit of the ring main unit 2 of	
8	the MVS has been powered off and safety	
	measures have been taken, and	
	maintenance can be carried out.	




Figure 5-4 the switch status after maintenance

# 5.2.3. Cables between Ring Main Units

This section takes the second MVS (MVS 2) as an example, and take the MVS 1 and MVS 2 as an example to introduce the power off and maintenance procedures between MVSs.

## 5.2.3.1. Ring main unit G1 is cabinet C

The switch status before maintenance:




Figure 5-5 the switch status before maintenance

Steps	Operation	Yes/No	Note
1	Remote control the opening of this level LV		
1	cabinet 1QF air circuit breaker.		
2	Remote control the opening of this level LV		
	cabinet 2QF air circuit breaker.		
	G2 cabinet of this level: opening vacuum circuit		
3	breaker, opening three position disconnector,		
	closing earthing switch.		
4	Remote control the opening of the next level LV		
4	cabinet 1QF air circuit breaker.		

5	Remote control the opening of the next level LV	
5	cabinet 2QF air circuit breaker.	
	All the G2 cabinet of the next level: opening	
6	vacuum circuit breaker, opening three position	
	disconnector, closing earthing switch.	
	The upper lever G3 cabinet: open the load	
7	switch, observe that the live display of G3	
/	cabinet is not flashing, and close the earthing	
	switch. Install prohibited operation signs.	
	This lever G1 cabinet: open the load switch,	
8	observe that the live display of G1 cabinet is not	
0	flashing, and close the earthing switch. Install	
	prohibited operation signs.	
	Both ends of the cable between the MVS 1 and	
	the MVS 2 have been grounded and safety	
9	measures have been taken, and the cable room	
	doors at both ends of the cable have been	
	unlocked and can be inspected.	




Figure 5-6 The switch status after maintenance

# 5.2.3.2. Ring main unit G1 is Cabinet D




Figure 5-7 The switch status before maintenance

Steps	Operation	Yes/No	Note
1	Remote control the opening of this level LV		
1	cabinet 1QF air circuit breaker.		
2	Remote control the opening of this level LV		
	cabinet 2QF air circuit breaker.		
	G2 cabinet of this level: opening vacuum circuit		
3	breaker, opening three position disconnector,		
	closing earthing switch.		
4	Remote control the opening of all the next level		
4	LV cabinet 1QF air circuit breaker.		
5	Remote control the opening of all the next level		
J	LV cabinet 2QF air circuit breaker.		
	All the G2 cabinet of the next level: opening		
6	vacuum circuit breaker, opening three position		
	disconnector, closing earthing switch.		
	The upper lever G3 cabinet: open the load		
7	switch, observe that the live display of G3		
	cabinet is not flashing, and close the earthing		
	switch. Install prohibited operation signs.		
	Both ends of the cable between the MVS 1 and		
8	the MVS 2 have been grounded and safety		
	measures have been taken, and the cable room		

doors at both ends of the cable have been unlocked and can be inspected.




Figure 5-8 the switch status after maintenance

## 5.3. Routine maintenance

Routine inspection and maintenance must comply with the relevant regulations of the power company. Inspection, maintenance and repairs can only be performed by trained personnel who are familiar with the equipment. Personnel must be certified and comply with safety regulations issued by the power company.

Inspection item	Inspection method	Period
	Check whether the MVS and internal	
	equipment are damaged or deformed.	
	Check whether there is abnormal noise	
	during the operation of the internal	
	equipment.	
System	Check whether the temperature inside the	
Status and	MVS is too high.	Once a month
Cleaning	Check that warning signs, labels, etc. are	
	clearly visible and not defaced. Replace	
	them if necessary.	
	Check whether the humidity is too high and	
	dust too series, and clean the equipment if	
	necessary.	

	Check whether there is oxidation or	
	corrosion inside the MVS. If present,	
	arrange a rust removal.	
	Check the water drain grooves at the	
	bottom of the TR room. Clean them	
	immediately if necessary to prevent	
	clogging.	
	Clean or replace the dust filter.	Once every half
	Check the operating status of the fan/heat	a year after the
Fan / heat	exchanger.	first
exchanger /		commission-ing
air		, and once
condition	Check whether the fan / heat exchanger	every half a
	makes abnormal sound during operation	year, once a
		year thereafter
	Check whether the power cable is loose. If it	Once every half
	is loose, tighten it according to the torque	a year after the
	specified in the manual.	first
Cable	Check whether the power cables and control	commission-ing
connection	cables are damaged, especially whether the	and once every
	layer in contact with the metal surface has	two years
	any signs of cuts.	thereafter

	Check whether the insulating wrapping tape	
	of the power cable terminal is peeled off	
	Check the SF6 barometer to see if the	
	pointer is within the green range. If the	
	pointer approaches red, please stop the	
	operation and replenish gas to it.	Once a month
	Check the live indicator and check whether	Once a month
MV ring	the L1 / L2 / L3 indicator is normal. If it is	
main unit	abnormal, please replace the L1/L2/L3	
	indicator lights when the power is off.	
	Conduct a manual operation test on the	
	operating mechanism to check the	Once a year
	flexibility. If it is hard to close or open,	Once a year
	please repair in time.	
	During operation, check whether the sound	
	of the transformer is normal.	
	Check the transformer oil level indicator. If	
Transforme	the oil level is low, please power off the MVS	Once a month
r	and fill in oil in time	Office a month
	Check whether there is oil leakage around	
	the pressure relief valve. If yes, tighten the	
	valve or replace parts.	

	Check the sheath of LV cabinet and HV	
	cabinet to see if there is oil leakage. If yes,	
	tighten the valve or replace parts.	
	Check whether there is oil leakage at the	
	joint between the transformer heat sink and	
	the oil tank flange. If yes, please tighten the	
	valve or replace parts in time.	
	Check whether the real-time temperature of	
	the oil thermometer is normal. If abnormal,	
	measure the resistance of PT1/PT2 and PT3	
	with a multimeter.	
	If the result is unqualified, it means that the	
	temperature gauge is faulty and needs to be	
	repaired in time.	
	Clean the surface of the transformer oil	
	tank, oil pillow, chips and other parts, and	Onco a voar
	tighten the bolts such as the foundation,	Once a year
	grounding and main circuit.	
	Check whether the lightning arrester	
IV saletant	indicator is normal (green) or faulty (red).	Onco a month
LV cabinet	Check for condensation on interior side	Once a month
	panels and top cover	

		I
	Check whether the indication of voltage,	
	current meter and opening and closing	
	indicator light in LV incoming cabinet are	
	normal. If abnormal, it needs to be replaced	
	in time.	
	Conduct closing and opening experiments	
	on the LV cabinet ACB.	
	Carry out a leakage test on the residual	Once half a
	current circuit breaker, and press the test	
	button to make the circuit breaker operate	year
	to check whether the circuit breaker is	
	normal.	
	Replace damaged lamps promptly.	
Other	Replace damaged smoke sensors and fire	Whon
equipment	extinguishers promptly	When
S	Replace the temperature and humidity	necessary
	controller in time.	

## 5.4. Common parts replacement

## **5.4.1. Replacement of Arrester**

#### **NOTICE**

Do not replace the arrester on rainy days.

Replacement steps (see the arrester user manual for details):

- 1. The arrester is located in the cable room of the circuit breaker cabinet of the ring main unit. Open the cable room door and you will see it.
- 2. Loosen the fixing bracket of the arrester to be replaced (M10 external hexagonal bolt)
- 3. Remove the grounding cable of the arrester to be replaced.
- 4. Remove the insulation cap and insulation plug of the arrester.
- 5. Remove the nut (M12 nut) on the conductive rod assembly.
- 6. Pull out the arrester.
- 7. Remove the conductive rod assembly and replace it with a new one (10mm wrench).
- 9. Install a new lightning arrester
- 10. Fasten the nut of the conductive rod assembly (M12 nut)
- 11. Install insulation plugs and rubber caps
- 12. Reinstall the grounding cable.
- 13. Fasten the fixed bracket of the arrester.




Figure 5-9 Lightning arrester and separable insulating sleeve


# **5.4.2. Replacement of Air Circuit Breakers**

#### **NOTICE**

Make sure the equipment is powered off and the air circuit breaker is in the "OFF" position

#### Steps:

1) Remove the copper bar at the back of the ACB.



2) Remove the signal cable and grounding cable of the air circuit breaker and mark them.



3) Remove the fixing bolts between the ACB and basement (M10 external hexagonal bolts).



- 4) Replace with a new air circuit breaker and tighten the bottom fixing bolts.
- 5) Reinstall the copper bar, signal cable and grounding cable, and tighten the fixing bolts of the air circuit breaker base.

## **5.4.3. Replacement of Molded Case Circuit Breakers**

#### **NOTICE**

- If need replacement, please contact Goodwe after-sales service or local Goodwe staff according to the spare parts list.
- If the short-circuit fault current <= ICU (ultimate short-circuit breaking capacity), after one short-circuit fault occurs, the circuit breaker needs to be replaced.
- If the short-circuit fault current <= ICS (operational short-circuit breaking capacity), the circuit breaker needs to be replaced after three short-circuit faults.
- Make sure the equipment is powered off and the breaker is in the "OFF" position.

#### Steps:

1) Remove the upper cover of the MCCB.





2) Remove the copper bars and cables connected to the upper and

## lower ends of the molded case circuit breaker.





3) Remove the fixing bolts of the molded case circuit breaker and remove the molded case circuit breaker.



- 4) Replace with a new molded case circuit breaker and fix the circuit breaker on the support plate and tighten it.
- 5) Restore the removed copper bars and cables to their original state.
- 6) Install the upper cover of the molded case circuit breaker.

# 5.4.4. Oil surface temperature gauge replacement Operational steps:

### 5.4.4.1 Disassemble the probe of the oil surface temperature gauge

Loosen the transition nut with a wrench, remove the probe, and promptly clean the transformer oil drips on the probe during removal by wiping and cleaning.

#### 5.4.4.2 Remove the oil surface temperature gauge cover

Rotate the oil surface temperature gauge cover counterclockwise slowly, then lift it off.

# 5.4.4.3 Remove the connection wires of the oil surface temperature gauge

- (1) Lift the cover plate at the bottom of the oil surface temperature gauge, take a photo to record the wiring positions before disconnecting.
- (2) Use a screwdriver to unscrew the corresponding screws, then pull the connection wires out from the bottom outlet of the oil surface temperature gauge, ensuring that the digital display tube does not fall off during the extraction process.

#### 5.4.4.4 Remove the oil surface temperature gauge

Use a screwdriver to remove the screws that secure the oil surface temperature gauge in place.

#### 5.4.4.5 Replace the oil surface temperature gauge and probe

(1) Take a qualified oil surface temperature gauge along with the matching screws. Install the fixing screws of oil surface temperature gauge by following these steps (lightly shake to ensure no looseness): Remove the cover of the oil surface temperature gauge. Lift the bottom cover plate. Insert the wires through the bottom opening. Connect the wires according to the recorded wiring configuration. Secure the connections by gently pulling on the wires to ensure they are snug. Close the bottom cover plate. Replace the temperature gauge cover.

Note: Verify if the temperature settings for the over-temperature alarm

and over-temperature trip pointer on the temperature gauge panel comply with the requirements on the blueprint.

- (2) Wrap Teflon tape around the threads of the temperature control probe of the temperature gauge. (Note: Wrap the Teflon tape in a clockwise direction to ensure proper tightening.)
- (3) Refilling oil: Inject transformer oil (same as the oil used for the transformer) into the temperature gauge probe seat. It is necessary to control the amount of oil injected. The standard is to fill just above the position where the probe seat meets the container wall weld seam, as indicated by the arrow. (If the deviation near this position is minimal, oil injection may not be necessary.)
- (4) Coil the excess length of the capillary tube into a circle with a diameter not less than Φ150mm. Secure the coiled tube to the base of the temperature gauge using cable ties. Note: During installation, special attention should be paid to protecting the capillary tube of the temperature gauge to prevent it from fracturing due to small bending radii.
- (5) Probe Installation: Insert the PT100 temperature probe of the temperature gauge into the oil surface monitoring hole. Ensure that the probe can enter the base without causing oil spillage. First, tighten the transition nut, adjust the orientation of the sensor leads, wrap the fastening nut with thread seal tape, and then tighten it. Note: Under no

circumstances should the indicator pointer be turned counterclockwise, as this can damage the temperature gauge.


# **5.4.5. Replacement of Micro Circuit Breakers**

#### NOTICE

Ensure that the equipment is powered off and place the micro circuit breaker in the "OFF" position

## Steps:

1) Remove the cables connecting the upper and lower ends of the micro circuit breaker.



2) Remove the micro circuit breaker.



- 3) Replace with a new micro circuit breaker and secure it onto the rail.
- 4) Restore the cables connecting the upper and lower ends of the micro circuit breaker to their original state.

# 5.4.6. Replacement of lighting lamps

Steps:

1) Remove the cable from the power supply terminal of the lighting lamp and mark it (unscrew the cable terminal cover and press the plastic part as shown in figure with your hand to pull out the cable).





2) Remove the lamp fixing screws (M6 external hexagonal bolts) and remove the lamp.



- 3) Replace with new lamp and fix it in place.
- 4) Restore the lamp power supply cable as it is.

## 5.4.7. Replacement of smoke sensor

Steps:

1) Hold the smoke sensor body and rotate it counterclockwise to separate the card on the sensor from the card fixed on the base as shown in figure. Remove the sensor.





2) Insert the new smoke sensor into the base and rotate it clockwise to the locking position.





# 5.4.8. Replacement of heater

The heating plate is located under the cable room of the LV cabinet.



### Steps:

- 1) Remove the cables on the heating plate and mark them
- 2) Remove the fixing screws of the heating plate (M6 and M4 screws)
- 3) Replace with a new heating plate and secure it
- 4) Restore the heating plate cable to its original status.

## 5.4.9. Replacement of Measuring and controlling Device

#### **NOTICE**

- 1. Please ensure that the equipment is powered off before replacing the measuring and controlling device.
- 2. Before replacing the measuring and controlling device, please ensure that the secondary side of the current transformer cannot be open circuited.

#### Steps:

1) The measuring and controlling device is located on the side surface panel of the LV cabinet.



2) Open the cabinet where the device is located, remove the cables on the back of the device, and mark the recording location; You can also remove the entire plug-in terminals and install them in the corresponding position of new devices.



3) Remove the screws that fix the device, and remove the device (M6 external hexagonal bolts).



- 4) Replace with a device and fix it in its original position.
- 5) Restore the cables on the back of the device to its original status.

# 5.4.10. UPS replacement

#### Steps:

1) Remove the cable from the back of the UPS and unplug it.





2) Remove the UPS fixing bracket and take out the UPS (M8 semi-round head square neck bolt)






- 3) Replace with a new UPS and secure it.
- 4) Restore the cables and plugs on the back of the UPS to the original status.

## 5.4.11. Replacement of the Heat Exchanger Rain Shield

#### **NOTICE**

The rain shield only applies to SF6 MVS Smart Transformer Station.



Step:

1) Remove the fixed screws of the heat exchanger rain shield and take

off the rain shield (M4 pointed tail self-tapping screws).

- 2) Open the LV room door, remove the cable of the heat exchanger, and mark them properly.
- 3) Remove the fixed screws around the heat exchanger and take off the heat exchanger (M6 external hex bolts).
- 4) Replace with a new heat exchanger and fix it.
- 5) Reinstall the heat exchange upper cable as its original status.
- 6) Reinstall the heat exchange rain shield as its original status.

# 5.4.12. Replacement of the air conditioner

Steps:

1) Open the door of the power distribution room, remove the cables on the air conditioner, and mark them.



2) Remove a circle of fixing screws around the air conditioner and remove the air conditioner (M5 hexagon socket bolts)



3) Replace with a new air conditioner and fix it.

4) Restore the air conditioning cable to its original status.

## 5.4.13. Replacement of the Moisture Absorber

1. Move the moisture absorber sealing plate with an adjustable wrench, and retain the four M12×25 bolts, as shown in the following image.



2. Remove the moisture absorber packaging, peel off the sealing reminder label, and place the rubber gasket onto the flange opening, as shown in the figure below.



Rubber gasket



3. Installed rubber gasket to the capsule breathing port flange with the four M12×25 bolts removed earlier.

**Note:** When tightening the bolts, first pre-tighten them and then tighten them diagonally in sequence. The required tightening torque is 33 N·m, and the compression of the rubber gasket should be approximately 1/3.







- 4. Remove the lower end cap of the moisture absorber.
- 5. Draw oil through the oil drain valve and fill the moisture absorber end cap between the two red lines. (Note: When drawing oil, place several clean cloths under the oil drain valve and slowly open the valve to collect the oil.)





6. Install the moisture absorber end cap filled with transformer oil.

## 5.5. Paint Repairing

Degree of paint damage	Tools and materials	Steps
Shallow	Small area paint	1. Use fine sandpaper to polish the
scratches(n	repairmen:	damaged areas and remove stains or rust.
o exposed	hand spray	2. Moisten the cotton cloth with alchol,
steel base	paint or brush	wipe the polished area or the area to be
material)	Large area paint	repaired to remove surface dirt and dust,
Stains and	repairmen: fine	and then wipe dry with clean cotton cloth.
rust that	sandpaper,	3. Choose according to the degree of
cannot be	alchol, cotton	damage, the size of the damaged area of

wiped off	cloth, spray	the paint surface, and the existing
	gun.	conditions: Use one of the methods of
		spray painting, brushing, or spray gun
		spraying to evenly repair the damaged
		areas of the coating until no trace of
		damage to the coating is exposed.
		4. The paint film should be as thin and
		uniform as possible,and the paint film
		should not be in the shape of droplets, and
		the surface should be kept smooth; after
		painting, leave it for about 30 minutes for
		the paint to solidify.
	Small area paint	
	repairmen:	
Deep scratches (exposed steel base material)	hand spray,	1. Same as above step 1
	zinc-rich	2. Same as above step 2
	primer,brush	3. Use paint or a spray gun to touch up the
	Large area paint	damaged areas with zinc-rich primer.
	repairment: fine	4. Same as above step 3
	sandpaper,	5. Same as above step 4
	alchol, cotton	
	cloth, spray	

gun.	

#### Notes:

- (1) The paint color shall refer to the color number specified in the contract.
- (2) Before paint repairmen, cover other colored parts except damaged paint with tape and white paper to avoid contamination of other parts during the touch-up operation.
- (3) If the base material is exposed in the area to be repaired, you must first apply the epoxy zinc-rich primer until the base material is not exposed after the paint dries, and then apply the topcoat.
- (4) Choose epoxy Zinc-rich primer as the primer, and choose the topcoat according to the color of the surface coating.

## 5.6 Transformer Operation

#### NOTICE

When operating the transformer, ensure it is in a de-energized state, meaning both the high-voltage and low-voltage sides of the transformer must be without power.

## 5.6.1 Adjustment of No-Load Tap Changer

The no-load tap changer is used to adjust the transformer's output voltage. Ensure that the transformer is de-energized (i.e., both the

high-voltage side and low-voltage side are disconnected from the power source) before operating the no-load tap changer.

When the voltage on the low-voltage side remains constant, the output voltage on the high-voltage side for different tap positions is as follows:


- Position 2: Rated Voltage × 1.025
- Position 3: Rated Voltage
- Position 4: Rated Voltage × 0.975
- Position 5: Rated Voltage × 0.95

#### NOTICE

**Example for adjusting the no-load tap changer:** If the low-side voltage is below 800V, adjust the changer towards Position 5.

Adjust the no-load tap changer to the position required.

The procedure for adjusting the tap changer (using adjustment to Position 1 as an example) is as follows:



## **5.6.2 Oil Sampling from the Transformer**

1. Loosen the plug on the sampling valve with an adjustable wrench, then unscrew it by hand. The result after removal should be as shown below.







2. Place an oil bottle beneath the outlet, then open the sampling valve to collect the oil sample, as shown in the following diagram.





- 3. Once sampling is complete, tighten the sampling valve and clean the sampling port with a clean white cloth.
  - 4. then secure the sampling valve plug using an adjustable wrench.





#### **5.6.3 Transformer Oil Draining Procedure**

1. Remove the moisture absorber. After removal, the unit should appear as shown in the diagram below.



#### 2. Draining the Oil

- 2.1 Open the air release plug at the top of the conservator with an adjustable wrench.
- 2.2 Remove the bolts from the butterfly valve's protective cover and visually confirm that the butterfly valve is in the open position to ensure the oil passage is unobstructed.



2.3 Locate the oil drain/fill valve at the bottom of the transformer, and prepare a draining rig similar to the one shown in the diagram below.



2.4 Securely fasten the draining rig which matches the flange of the drain/fill valve, to the valve's flange using bolts of the corresponding specification. Then connect a pre-prepared flexible oil hose to the rig.




2.5 Connect one end of the flexible oil hose to the draining rig and ensure a tight connection to the transformer's bottom drain/fill valve. Place the other end of the hose into a prepared empty oil drum (the drum must be dry and clean), and secure it with rope. Open the drain/fill valve. The oil inside the transformer can then be drained into the empty drum by gravity.

## **5.6.4 Venting Operation of the Gas Relay**

When gas is observed inside the cavity through the glass inspection window of the gas relay (i.e., the oil level surface is visible within the glass window), a venting operation is required.

- 1. Open the cover plate of the gas relay.
- 2. Remove the vent plug nut.
- 3. Loosen the vent plug bolt. The vent plug will gradually release the gas inside the cavity until oil droplets emerge, then the venting finished.

The Figure shows the Venting Gas from the Gas Relay



4.

Tighten the vent plug bolt, reinstall the vent plug nut, and reattach the gas relay cover plate.

# **6. Technical Parameters**

Transformer	GW3520K-MVS	GW7040K-MVS	GW9100K-MVS
Transformer Type	Oil immersed	Oil immersed	Oil immersed
Rated Power (kVA)	3520kVA@40°C	7040kVA@40°C	9152kVA@40℃
Vector Group	Dy11	Dy11-y11	Dy11-y11
LV/MV Voltage (kV)*1	0.8/10~35	0.8/10~35	0.8/20~35
Maximum Input			
Current at Nominal	2526	2*2526	2*3302
Voltage (A)			

Transformer	GW3520K-MVS	GW7040K-MVS	GW9100K-MVS
Frequency (Hz)	50/60	50/60	50/60
Tapping Range	±2*2.5%	±2*2.5%	±2*2.5%
Peak Efficiency Index	≥99%	≥99%	≥99%
Cooling Type	ONAN (Oil Natural Air Natural)	ONAN (Oil Natural Air Natural)	ONAN (Oil Natural Air Natural)
Impedance	7% (±10%)	8% (±10%)	9.5% (±10%)
Oil Type	Mineral oil (PCB free)	Mineral oil (PCB free)	Mineral oil (PCB free)
Winding Material	Al/Al	Al/Al	Al/Al
Insulation Class	Class A	Class A	Class A
MV Switchgear			
Insulation Type	SF6 free/SF6	SF6 free/SF6	SF6 free/SF6
Rate Voltage (kV)	12~40.5	12~40.5	24~40.5
Rate Current (A)	630	630	630
Internal Arcing Fault	IAC AFL 20 kA/1s Optional:25kA/1s	IAC AFL 20 kA/1s Optional:25kA/1 s	IAC AFL 20 kA/1s Optional:25kA/1s
Qty.of Feeder	3 feeders (IBI) *2/3 feeders (DCV, Optional: CCV)	3 feeders (IBI)  *2/3 feeders  (DCV, Optional:  CCV)	3 feeders (IBI) *2/3 feeders (DCV, Optional: CCV)
Surge Protection	NA	NA	NA
LV Room			
ACB Specification	3200A/800Vac/3P, 1 pcs	3200A/800Vac/3 P, 2 pcs	4000A/800Vac/3P, 2 pcs
MCCB Specification	320A /800Vac/3P, 10pcs	320A /800Vac/3P, 20pcs	320A /800Vac/3P, 26pcs
Protection			
AC Input Protection	Circuit breaker	Circuit breaker	Circuit breaker
Transformer Protection	Oil-temperature, oil-level, oil-pressure	Oil-temperature , oil-level, oil-pressure	Oil-temperature, oil-level, oil-pressure
LV Overvoltage Protection	AC Type I+II	AC Type I+II	AC Type I+II
General Date			
Dimensions (W×H×D) (mm)	6058*2896*2438	6058*2896*243 8	6058*2896*2438
Approximate Weight	<15	<23	<25

Transformer	GW3520K-MVS	GW7040K-MVS	GW9100K-MVS
(t)			
Operating Temperature Range	-25 to 55 (≥40°C	-25 to 55 (≥40°C	-25 to 55 (≥40°C
(°C)	derating)	derating)	derating)
Auxiliany Dowor	5 kVA/400V	5 kVA/400V	5 kVA/400V
Auxiliary Power	(Optional: max.	(Optional: max.	(Optional: max.
Supply	50kVA)	50kVA)	50kVA)
Ingress Protection Rating	IP54	IP54	IP54
Relative Humidity	0 – 95 % RH	0 – 95 % RH	0 – 95 % RH
Max. Operating	1000 (Optional:	1000 (Optional:	1000 (Optional:
Altitude (m)	2000)	2000)	2000)
Anti-corrosion Class	C4H (Optional: C5M)	C4H (Optional: C5M)	C4H (Optional: C5M)
Noise Emission (dB)	55	55	55
	Standard: RS485,	Standard:	Standard: RS485,
Communication	Ethernet	RS485, Ethernet	Ethernet
Communication	Optional: Optical	Optional:	Optional: Optical
	Fiber	Optical Fiber	Fiber
	IEC 60076, IEC	IEC 60076, IEC	IEC 60076, IEC
	62271-200, IEC	62271-200, IEC	62271-200, IEC
Compliance	62271-202, IEC	62271-202, IEC	62271-202, IEC
	61439-1/2,	61439-1/2,	61439-1/2,
	EN50708-1, CE	EN50708-1, CE	EN50708-1, CE

## Note:

\*1: SF6 Free: LV/MV Voltage (kV) is 0.8/10-24kV

\*2: 3 feeders (IBI) for SF6 free


# 7. Appendix

Protecting Earthing	
Medium Voltage Station	
Operations &Maintenance	
Direct Current	
Alternating Current	
Medium Voltage	
Low Voltage	
Ring main unit	
Surge Protection Device	
Uninterruptible Power Supply	
Fuse	
Molded Case Circuit Breaker	
Micro Circuit Breaker	
Air Circuit-Breaker	
Vacuum Circuit Breaker	
Power Line Communication	
Personal Protective Equipment	



Official Website

### GoodWe Technologies Co., Ltd.



www.goodwe.com



**Contact Information**